

# 50 Series Motor Limit Setting

---

- Gently remove the yellow cap from side of motor
- Beneath the cap you will find two push buttons
- Yellow sets the clockwise rotation, white sets the counter-clockwise rotation
- Make sure that both buttons are in the depressed position

\*If the motor is mounted on the right end of the shade the yellow button will set the lower limit. The white button will set the upper limit. The opposite will be true for the left end motors.

- With both the yellow and white buttons in the depressed position, the shade will move up and down. Use the motor tester cable to check your rotational direction. If the motor direction is reversed turn the power off and simply reverse the black and red motor leads.

- Push the up button on the motor test cable to position the shade in the desired upper position and press the white button, to set the upper limit.

- Push the down button on the motor test cable to position the shade in the desired lower position and press the yellow button to set the lower limit.

\*For reversed roll application, the opposite is true for motor right or left.

