

Sonesse 50, Ultra 50, LT50 limit setting

- Gently remove the yellow cap from side of the motor
 - Beneath the cap you will find two push buttons
 - Yellow sets the clockwise rotation, white sets the counter-clockwise rotation
 - Make sure that both buttons are in the depressed position
 - If the motor is mounted on the right end of the shade the yellow button will set the lower limit. The white button will set the upper limit. (the opposite will be true for the left end motor)
 - With both the yellow and white buttons in the depressed position, the shade will move up and down in response to the wall switch
- Push the up button on the wall switch to position the shade in the desired upper position and press the white button, to set the upper limit.
 - Push the down button on the wall switch to position the shade in the desired lower position and press the yellow button to set the lower limit.

