



Installation • Operation • Care



Vertical Blind Collection
Manual Operating System

CONTENTS

GETTING STARTED 1

Product View..... 1

Tools and Fasteners Needed 2

INSTALLATION 3

Installation Overview..... 3

Valance Assembly..... 4

Mount the Installation Brackets — Inside Mount..... 6

Mount the Installation Brackets — Outside Mount..... 8

Install the Vanes 10

OPERATION..... 11

CARE..... 12

Removing the Headrail (If Necessary)..... 12

Removing the Vanes (If Necessary)..... 12


Cleaning Procedures 12

CHILD SAFETY 13

WARRANTY 14

Questions?
Contact Hunter Douglas Consumer Support at help.hunterdouglas.com.

Product View



GETTING STARTED

Thank you for purchasing Hunter Douglas Vertical Blinds. With proper installation, operation, and care, your new blind will provide years of beauty and performance.

Please thoroughly review this instruction booklet and the enclosed packing list before beginning the installation.

Tools and Fasteners Needed

- Flat blade and Phillips screwdriver
- Level (laser level is recommended)
- Measuring tape and pencil
- Power drill, $\frac{3}{32}$ " drill bit, and $\frac{1}{4}$ " hex driver

In addition, you will need fasteners designed to work with your specific mounting surface(s).


- **#7 Hex Head Screws (Provided).** Two 1½" screws are provided per installation bracket.



#7 x 1½"
Hex Head Screw
(Provided)

Installation Overview

Your order will include installation brackets specific to your blind. The number of installation brackets required varies with headrail width, as shown in the table.






Blind Width	Brackets Required
Up to 41"	2
41 1/8" – 81"	3
81 1/8" – 121"	4
121 1/8" – 161"	5
161 1/8" – 188"	6

Mounting Types and Window Terminology

If the installation brackets are mounted correctly, the rest of the installation process follows very easily. To prepare for this important first step, review the mounting types and basic window terminology illustrated below.

Molding (or Wall)



■ **If your blind has a valance go to — Page 4.** Otherwise, go to your mounting option below:

- **Inside Mount — Page 6**
- **Outside Mount — Page 8**

INSTALLATION


Valance Assembly

Please refer to the section below for your valance type.

If you didn't order a valance, proceed to "Mount the Installation Brackets — Inside Mount" on page 6 or "Mount the Installation Brackets — Outside Mount" on page 8 based on the mounting option ordered.

Square Valance Assembly


- Insert the square valance corners into the valance on either side as shown.
- Insert the valance returns into the corners as shown



Rounded Corner Valance Assembly

(Not available in Canada)

- The valance should arrive fully assembled. If a component has come loose, insert as shown here.




Proceed to “Mount the Installation Brackets — Inside Mount” on page 6 or “Mount the Installation Brackets — Outside Mount” on page 8 based on the mounting option ordered.

INSTALLATION

Mount the Installation Brackets — Inside Mount

- Mark 2" to 4" in from each jamb. Measure and mark the underside of the valance cover, if ordered.
- If more than two installation brackets came with your order, space additional bracket(s) provided evenly in 24" to 30" intervals between the end brackets and mark their location. Mount into wood whenever possible.

IMPORTANT: Allow ½" clearance between vane and window.



Install Mounting Clips

- Drill the screw holes using a ⅜" drill bit.




WARNING: Product is heavy. Mount into wood/metal studs or into concrete with concrete anchors. Drywall anchors are not recommended.




- If you did not order a valance, drill directly into the ceiling/head jamb.
- If you ordered a valance, drill through the rear groove of the valance then into the ceiling/head jamb.
- Attach the mounting clip using the screws provided.
- Hold the valance in position, the screw will go (through the valance, if ordered) into the ceiling/head jamb.

- Center the headrail underneath the mounting clips.



- Tilt the headrail and insert it into the front edge of the mounting clips. Pull forward, then roll the headrail back toward the rear of the blind. Push up and snap into place.




Proceed to "Install the Vanes" on page 10.

INSTALLATION

Mount the Installation Brackets — Outside Mount

- Mark 2" to 4" in from each jamb.

- If more than two "L" installation brackets came with your order, space additional bracket(s) provided evenly in 24" to 30" intervals between the end brackets and mark their location. Mount into wood whenever possible.
- Adjust mounting clips to allow $\frac{1}{2}$ " clearance between the vane and the wall (i.e. $2\frac{1}{4}$ " for $3\frac{1}{2}$ " vane).





- Drill the screw holes using a $\frac{3}{32}$ " drill bit.




WARNING: Product is heavy. Mount into wood/metal studs or into concrete with concrete anchors. Drywall anchors are not recommended.

- Attach the brackets using the screws provided.
- Center headrail underneath mounting clips.
- Tilt the headrail and insert it into the front edge of the mounting clip. Pull and roll the headrail up toward the rear of the blind and snap into place.



- If a valance is included, “snap” on a valance hanger next to each “L” bracket.
- Center the valance in relationship to the headrail and slide it into the valance hangers.




INSTALLATION


Install the Vanes

- Determine the desired light/view direction. Rotate the vane hooks so the slot between the long and the short prong is facing you.

Top View




- Push the vane into the hook until it “snaps” into place.



Wand Control


- **Traversing.** Push or pull the wand to open or close the vanes.

NOTE: Please do not bow the wand. Hold the wand at a 45° angle. Push or pull the wand to open or close the vanes.



- **Tilting.** Twist the wand to open or close the vanes.


IMPORTANT: Do not over torque the wand. It can cause the vanes to kick out at the bottom of the blind and cause the vanes to look misshapen.



CARE

Removing the Headrail (If Necessary)

- To remove the headrail, locate the rear tab on the mounting clip.
- Push up on the rear tab to release the headrail.



Removing the Vanes (If Necessary)

- Push up on the vane.
- Gently open the vane hook by inserting a 'credit card' sized piece of rigid plastic between the vane and the long prong of the vane hook.
- Carefully remove the vane.

Cleaning Procedures

Dusting

- Regular light dusting with a feather duster is all the cleaning that is needed in most circumstances.

Vacuuming

- Use a hand-held vacuum with low suction for more thorough dust removal.

Spot-Cleaning

- Prepare a solution of warm water and a mild detergent.
- Dampen a clean cloth in the solution and wring it out.
- Dab the spot with the dampened cloth until it is gone.

CAUTION: Vertical fabrics should not be spot-cleaned or immersed in water.

Compressed Air

- You can use compressed air or a hair dryer (cool setting) to blow the dust off your valance.

**Window Blind Cord Strangulation Risk**

A damaged, loose, or missing tension device poses a strangulation risk to children. Remove from use and repair or replace if tension device is damaged, loose, or missing.

Riesgo de Estrangulamiento en Cuerdas de Persianas

Un dispositivo tensor dañado, suelto o ausente representa un riesgo de estrangulamiento para los niños. Retire del uso y arregle o reemplace si el dispositivo tensor está dañado, suelto o ausente

LIFETIME GUARANTEE

The Hunter Douglas® Lifetime Guarantee is an expression of our desire to provide a thoroughly satisfying experience when selecting, purchasing and living with your window fashion products. If you are not thoroughly satisfied, simply contact Hunter Douglas at **(800) 789-0331** or visit **hunterdouglas.com**. In support of this policy of consumer satisfaction, we offer our Lifetime Limited Warranty as described below.

COVERED

BY A LIFETIME LIMITED WARRANTY

- Hunter Douglas window fashion products are covered for defects in materials, workmanship, or failure to operate for as long as the original retail purchaser owns the product (unless shorter periods are provided below).
- All internal mechanisms.
- Components and brackets.
- Fabric delamination.
- Operational cords for a full 7 years from the date of purchase.
- Repairs and/or replacements will be made with like or similar parts or products.
- Hunter Douglas motorization components are covered for 5 years from the date of purchase.

Hunter Douglas (or its licensed fabricator/distributor) will repair or replace the window fashion product or components found to be defective.

NOT COVERED

BY A LIFETIME LIMITED WARRANTY

- Any conditions caused by normal wear and tear.
- Abuse, accidents, misuse, or alterations to the product.
- Exposure to the elements (sun damage, wind, water/moisture) and discoloration or fading over time.
- Failure to follow our instructions with respect to measurement, proper installation, cleaning, or maintenance.
- Shipping charges, cost of removal and reinstallation.

TO OBTAIN WARRANTY SERVICE

1. Contact your original dealer (place of purchase) for warranty assistance.
2. Visit hunterdouglas.com for additional warranty information, frequently asked questions, and access to service locations.
3. Contact Hunter Douglas at **(800) 789-0331** for technical support, certain parts free of charge, for assistance in obtaining warranty service, or for further explanation of our warranty.

NOTE: In no event shall Hunter Douglas or its licensed fabricators/distributors be liable or responsible for incidental or consequential damages or for any other indirect damage, loss, cost, or expense. Some states do not allow the exclusion or limitation of incidental or consequential damages, so the above exclusion or limitation may not apply to you. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Different warranty periods and terms apply for commercial products and applications.

HunterDouglas 
hunterdouglas.com